


Wiring diagram: ComfoAir STANDARD - LEFT-HAND version



Wiring diagram: ComfoAir STANDARD - RIGHT-HAND version

